



ROCAL
MANUFACTURAS S.A.

DROP A4560

ANEXO/ANNEX/ANNEXE/ANESSO

I






ROCAL
MANUFACTURAS S.A.

Mini DROP A4561


ANEXO/ANNEX/ANNEXE/ANESSO

I







1 DROP




1 Mini DROP




2




3



4




A.1 Drop




II



A.1 Mini Drop




A.2




A.3




A.4



A.5




A.6




III


A.7




B.1 Drop




B.1 Mini Drop




B.2




B.3




B.4




B.5




B.6




B.7




B.8



B.9




B.10




II

B.11



B.12



B.13

Siga los pasos descritos en el manual del aparato a partir del paso “B.6”

Follow the steps described in the appliance manual from step “B.6”

Suivez les étapes décrites dans le manuel de l'appareil à partir de l'étape “B.6”

Seguire i passaggi descritti nel manuale dell'apparecchio dal passaggio “B.6”

Siga as etapas descritas no manual do aparelho a partir da etapa “B.6”



ROCAL

MANUFACTURAS SA

Manufacturas Rocal SA

Raval Sant Antoni, 2
08540 Centelles
Barcelona

www.rocal.es

man.rocal@rocal.es
T +34 93 8812451
F +34 93 8810631