


ROCAL  
MANUFACTURAS S.A.

# Ronde Frontal A4575

ANEXO/ANNEX/ANNEXE/ANESSO


I



I




2x



0.6 m

1x



4x




1x




3x


1x




1




2




3




4



5




A.1




# II


A.2




A.3




A.4




A.5



A.6



A.7




PAG. 5




# II


**B.1**




**B.2**




**B.3**




**B.4**




**B.5**




**B.6**




**B.6**




**B.7**




**B.8**




**B.9**




**B.10**




**B.11**



B.12



B.13



**Siga los pasos descritos en el manual del aparato a partir del paso “B.4”**

**Follow the steps described in the appliance manual from step “B.4”**

**Suivez les étapes décrites dans le manuel de l'appareil à partir de l'étape “B.4”**

**Seguire i passaggi descritti nel manuale dell'apparecchio dal passaggio “B.4”**

**Siga as etapas descritas no manual do aparelho a partir da etapa “B.6”**



**ROCAL**

**MANUFACTURAS SA**

**Manufacturas Rocal SA**

Raval Sant Antoni, 2  
08540 Centelles  
Barcelona

**[www.rocal.es](http://www.rocal.es)**

[man.rocal@rocal.es](mailto:man.rocal@rocal.es)  
T +34 93 8812451  
F +34 93 8810631