



MIRAGE 40i ELECTRIC QUICK START GUIDE



POWER ON/OFF
(LONG PRESS)



FLAME PRESETS
(SHORT PRESS LEFT & RIGHT TO SCROLL)



**HIGH
BURN**



**MEDIUM
BURN**



**LOW
BURN**



EMBERS



AURORA

● When a button is pressed, the LED will light green to confirm the command has been transmitted.
When the battery is low, the LED will light red when a button is pressed, indicating it needs to be replaced.

APP & VIDEO GUIDES

Access all the advanced features of the Mirage 40i, including daily and weekly scheduling, via the MyFlame app, available from Google Play or the App Store. The app makes it easy to fine-tune settings, manage timers, and customise your fireplace to suit your routine.



In addition, two handy video guides are available online, providing clear, step-by-step instructions on using both the app and the remote control, helping you get the most out of every feature with confidence.




onyxfires.com/howto

PR3400




MIRAGE 40i ELECTRIC QUICK START GUIDE

EFFECTS



*Please note: The Moodlighting feature is currently unavailable and will be launched at a later date.

HEATER



SETTINGS

