




ROCAL
MANUFACTURAS S.A.

DROP A4560

VEDLEGG

I






ROCAL
MANUFACTURAS S.A.

Mini DROP A4561


VEDLEGG

I






1 DROP




1 Mini DROP




2




3



4




A.1 Drop




II


A.1 Mini Drop




A.2




A.3




A.4



A.5



A.6




III


A.7




B.1 Drop




B.1 Mini Drop




B.2



B.3




B.4




II


B.5




B.6




B.7




B.8



B.9




B.10




II

B.11



B.12



B.13

Følg trinnene som er beskrevet i apparatets håndbok fra trinn «B.6»



ROCAL

MANUFACTURAS SA

Manufacturas Rocal SA

Raval Sant Antoni, 2
08540 Centelles
Barcelona

www.rocal.es

man.rocal@rocal.es
T +34 93 8812451
F +34 93 8810631